

GORSKI G2000SS HELMET

CAMERA / LIGHT BRACKET (PN 400107) INSTALLATION INSTRUCTIONS

This procedure is to be performed only by personnel who have received appropriate training. If you do not completely understand all of the procedure, contact Aqua Lung / Gorski to speak directly with a Technical Advisor before proceeding any further.

Step-by-Step Assembly Instructions



Step 1: Remove two retainer port screws from top corner of helmet using a Phillips #3 screwdriver.



NOTE: Brackets may be bent to shape as required.



Step 2: Line up bracket holes with helmet retainer holes.



Step 3: Replace the two retainer port screws and tighten using a Phillips #3 screwdriver to 45 in.lbs (5 Nm).



Step 4: Right hand bracket installed.



Step 5: Left hand bracket installed.



Step 6: Left and Right brackets.