

G2000SS DIVING HELMET
BRACKET, CAMERA/LIGHT, P/N 400107
INSTALLATION INSTRUCTIONS

This procedure is to be performed only by personnel who have received appropriate training. If you do not completely understand all of the procedure, contact Aqua Lung/Gorski.

Step-by-Step Assembly Instructions:



Step 1: Remove 2 screws from top corner of Helmet



Step 2: Line up Bracket holes with Helmet Retainer holes



Step 3: Replace the 2 screws and tighten until snug



Step 4: Right hand Bracket installed

NOTE:

The procedure shown is for the right Bracket. The procedure is the same for the left Bracket.

Step 5: Repeat procedure for other Bracket



Step 6: Left hand Bracket installed



Step 7: L and R Brackets



NOTE: Brackets may be bent to shape as required