



## FIRMWARE UPDATE RELEASE DETAILS

# i750TC

DIVE COMPUTER

to version 1D

(from any previous version)

### EXPLANATION

In response to input received from staff and users of the i750TC, Aqua Lung has corrected or modified the following items to improve the i750TC's operation:

- On previous versions of the firmware, a battery warning could clear if the battery recovered above the warning threshold. This battery recovery could be seen by moving the computer to different environments. This "recovery" would not be substantial enough to ignore the need to replace the battery. Additionally, returning to the original environment where the warning/alarm was previously triggered could lead to rapid battery deterioration. If a battery warning/alarm is triggered, the new firmware will continue to display the battery warning/alarm until the battery is replaced.

### UPDATE PROCESS

You can update your i750TC firmware (operating software) to newly released revision 1D by following the "How to Update Firmware to a Dive Computer" instructions in the DiverLog software. There is no need to return the unit to Aqua Lung.

***DiverLog is available on the <http://www.ediverlog.com> web site.***

Should you have any questions, please contact your Authorized Aqua Lung Dealer.