

CHECKLIST 4
G2000SS DIVING HELMET
POST-DIVE CHECKLIST

THE POST-DIVE CHECKLIST MUST BE COMPLETED AT LEAST ONCE A DAY WHEN DIVING USING THE G2000SS DIVING HELMET.



NOTE: *The procedures in this checklist are to be performed only by personnel who have received appropriate training.*





WARNING: Aqua Lung America strongly recommends completion of this checklist and meeting the minimum requirements provided before using the G2000SS diving helmet. However, these requirements are not conclusive, as further steps may be required depending on the type of activity performed. **FAILURE TO COMPLY WITH THIS CHECKLIST MAY RESULT IN SERIOUS INJURY OR EVEN DEATH.**

COMPLETE THE FOLLOWING BOXES PRIOR TO THE CHECKLIST

COMPLETE THE SIGNATURE, DATE AND COMMENTS AT THE END OF THE CHECKLIST

Helmet Serial No:	Date:
Diver/Tender: (Print Name)	

POST DIVE CHECKLIST (continued)

PROCEDURE	INITIALS
1. Secure and bleed down the breathing gas supply and the EGS hose.	
2. Disconnect all helmet gas connections and disconnect the communication wires / cable. Replace hose caps onto hose adapters after removing all water from the hose adapter.	
3. Wash the outside of the helmet and all external fittings completely with fresh water. This removes dirt and prevents surface corrosion. If required, wash with soap and water, rinse with fresh water and allow to dry.	
4. Visually inspect the helmet fully for damage.	
5. Remove the head liner. Visually inspect for damage and/or deterioration. If the head liner is wet, air dry it.  NOTE: <i>The liner may be washed as required.</i>	
6. If required, and particularly if the inside of the regulator was exposed to salt or contaminated water, remove the regulator and the oral-nasal mask from the helmet. Wash with soap and water, rinse with fresh water and allow to dry. DO NOT allow water to enter the regulator body. Re-install into helmet upon completion.  NOTE: <i>Refer to the technical manual for guidance on installation and removal of the regulator.</i>	
7. Remove the speakers.	

POST DIVE CHECKLIST (continued)

PROCEDURE	INITIALS
8. Remove the microphone from the oral-nasal mask. Wash the oral-nasal mask with soap and water, rinse with fresh water and allow to dry.	
9. Dry the inside of the helmet, including oral-nasal mask, by wiping. If required, wash with soap and water, rinse with fresh water and allow to dry.	
10. Clean neck dam, neck retainer and latch catches with soap and water, rinse with fresh water and allow to dry.	
11. Wipe helmet down to remove any standing water and allow to air dry. <u>DO NOT STORE A WET HELMET OR COMPONENTS.</u>	
12. Wash the outside of all EGS components, gas cylinder, submersible pressure gauge and the harness assembly with soap and water, rinse with fresh water and allow to dry.	
13. Any defects or damage found during post-dive procedures must be noted on the front page and brought to the attention of the supervisor and/or helmet technician.	

DEFECTS AND DAMAGES: Any defects or damages found during post-dive procedures must be noted and brought to the attention of the supervisor and/or technician.

Signature: _____

Date: _____

Comments: _____

